



2018年4月9日

A/2


Tolerance, Unless Otherwise Stated. Is	
Above 0.5 to and including 6	±0.1
Excess 6 to and including 30	±0.2
Excess 30 to and including 120	±0.3
Excess 120 to and including 315	±0.5
Excess 315 to and including 1000	±0.8
Excess 1000 to and including 2000	±1.2



1. 说明书双面印刷完成  
(297x210=A4) 共1张



2. 说明书折叠



3. 说明书折叠完成

制作说明:

1. 说明书完成的尺寸: 148\*210
2. 材料: 80克的白色纸
3. 印刷说明: 说明书为297x210(A4) 双面印刷, 并折叠成148x210大小完成(详看图示)
4. 印刷颜色: 黑白
5. 印刷时, 内容准确, 清晰, 墨色均匀, 表面清洁。

				DESIGN	黄卓桓	2018.03.19	TITLE	Instructions	
				CHECKED	付天心	2018.4.8	REF	卡斯图挂墙单柄双控浴缸/淋浴水嘴中英文说明书	
				APPROVED	李军学	2018.4.8		FFAS1611-609500BC0	无花洒
				SCALE	MATERIAL	WEIGHT	DWG NO.		
A2	改为中英文版本	2018.03					FFAS1612-709500BC0		
A1	改为New AS Logo <i>American Standard</i>	2017.12							
REV	DESCRIPTION	DATE	NAME				FF1-CN521K00113299	<i>American Standard</i>	

## Test / Usage 测试和使用


### 1 Test 测试

1. Move handle to "OFF" position. Turn on water at mains to check for any leakages.
  2. Move handle in all directions to ensure that handle is moving smoothly.
  3. Adjust handle to "ON" position to check water flow.
1. 使把手处在关闭状态, 打开供水系统, 检查各连接处是否有渗漏;  
2. 扳动把手, 检查把手是否灵活;  
3. 打开把手, 检查水嘴出水是否正常。

### 2 Usage 使用

**Warning:**  
When you use the faucet, please open the cold water first, then open the hot water slowly until you get a comfortable temperature for mixed water.

**注意:**  
使用双把手时, 请先开启冷水, 然后慢慢加入热水, 直到温度合适。



2018年4月9日  
A/2


## Trouble Shooting Guide 一般故障排除指南

Issue 故障	Component 检查点	Checkpoint 内容	Corrective Action 处理办法
Poor flow rate 流量小	Aerator 起泡器	Check any impurities 检查是否有杂质	Remove all impurities 清除杂质
	Water supply valve 供水阀	Check valve position 检查供水阀是否开得大小	Open it to full valve 开大供水阀
Leakage 漏水	Cartridge packing 阀芯	Check cartridge install 检查阀芯是否被松开	Fastening the cartridge; or replace the cartridge 紧固好阀芯
	Junction 各连接处	Check the connection 检查连接处是否未加垫片或垫片已损坏	reinstall 重新安装
Deviant Temperature 不正常水温	Water supply valve 供水阀	Check if the water from supply valve is enough or not 检查供水阀是否开得大小	Open the water supply valve 开大供水阀
	Water supply system 供水管路	Check if the supply pipe connected correct or not 检查进水管是否连接正确	Connect the hot and cold water pipe correctly 正确连接冷热供水管

## Care & Maintenance 维护与保养

- \* AERATOR may accumulate dirt causing distorted and reduced water flow. Remove and clean AERATOR and then replace it.
- \* If faucet drips, operate handle several times from "off" to "on". Do not apply excessive force.
- \* Clogged CARTRIDGE inlets may cause flow reduction in hot or cold water. To clean inlets, turn off water supply firstly.
- \* If you want to do the maintenance for the faucet, please follow the below process. After maintenance, to reset the parts, and test the water effect.

- \* 起泡器可能积累污垢致损害或影响出水效果, 此时应清洁或更换起泡器。
- \* 如果水嘴漏水, 旋动把手数次从关到开, 不要过度用力。
- \* 阀芯入口堵塞会导致冷、热水流量减少影响水流效果, 如需清洗, 请先关闭供水。
- \* 当你想做水嘴维护, 请遵循以下流程, 保养完毕, 重新装回和测试出水效果。




**Attention:**  
Please leave manual with customer post installation.

**安装者注意:**  
安装完成后, 请将此说明书留给用户。


## Kastello 卡斯图

FFAS1611-609500BC0  
Exposed B&S Mixer (W/O Shower)  
双柄双控挂墙式浴缸水嘴 (无花洒)

FFAS1612-709500BC0  
Exposed Shower Only Mixer (W/O Shower)  
双柄双控挂墙式淋浴水嘴 (无花洒)



FFAS1611-609500BC0



FFAS1612-709500BC0

American Standard



Thank you for selecting American-Standard - the benchmark of fine quality for over 100 years.

To ensure that your installation proceeds smoothly--please read these instructions carefully before you begin.

\* American Standard continually improves our product design and performance and reserves the right to modify the dimension and specification of our products accordingly without any prior notification.

\* This installation instruction sheet is for your reference only, the dimension and specification is subject to the actual products.

感谢您选购美标洁具—拥有百年优质水准的产品, 为保证安装顺利, 请在进行安装前细阅以下指南

\* 美标公司一贯奉行不断提高和改善其产品设计与性能的政策, 并保留对其产品规格更改的权力, 届时, 恕不另行通知。

\* 本指南仅供安装和使用作参考, 产品以实物为准。

## Pre-Installation Checks 安装前注意事项

\* All instruction procedures must comply in strict accordance with applicable local plumbing and building codes.

\* Remove all impurity in pipes before beginning to avoid clogging. Connect faucet pipes correctly.

\* Check installation distances in the Dimension diagram to ensure correct installation.

Conditions for use

\* Water pressure condition: 0.05-0.75MPa (Recommended water pressure condition: 0.1-0.5MPa)

\* Environment Temperature: 1-55°C

\* Water Temperature: 4°C-90°C, Recommended the highest hot water temperature 60°C

\* Steam is not allowed to use. The cold and hot water pipes must not be reserved.

When in the process of installation, grab the whole body. Do not grab handle only.

\* 所有的安装程序必须严格遵照当地的卫浴和建筑法规条例。

\* 安装水嘴之前, 请务必清理管中杂物, 以免造成堵塞; 水嘴与冷、热水水管必须连接正确。

\* 参考尺寸图, 检查安装尺寸, 确保安装正确。

使用条件

~ 使用水压 (包括冷水与热水压力): 0.05-0.75兆帕, 推荐使用水压: 0.1-0.5兆帕

~ 使用环境温度: 1~55°C

~ 使用水温: 4°C-90°C, 建议使用热水最高温度为60°C

~ 冷热水管不可调换, 不可使用蒸汽。

注: 安装时, 请握住水嘴主体进行操作, 不要仅握住把手进行操作, 以免损伤水嘴。

## Recommended Tools and Materials 推荐的工具和材料



Adjustable Wrench  
扳手



Level  
水平仪



Screwdriver  
螺丝刀



Tape Measure  
卷尺




Teflon Tap  
生料带


## Dimension 基本尺寸

Unit: mm  
单位: 毫米


FFAS1611-609500BC0



FFAS1612-709500BC0



Parts List 零件明细



2018年4月9日


A/2

Parts List 零配件明细表

No. 序号	Part Name 零件名称	Q'ty 数量	No. 序号	Part Name 零件名称	Q'ty 数量	No. 序号	Part Name 零件名称	Q'ty 数量			
		1611/1612			1611/1612			1611/1612			
1	S-connector S型接管	2	2	15	Lever 把手连接齿套	2	2	29	Washer 定位垫片	1	0
2	Washer 垫片	2	2	16	Washer 弹性垫片	2	2	30	O-ring O环	1	1
3	Escutcheon 孔罩	2	2	17	Bushing 把手衬套	2	2	31	Connector 转换接头	1	1
4	Connector 接头	2	2	18	Handle seat 把手座	2	2	32	Cartridge 阀芯	1	1
5	O-ring O环	2	2	19	Washer 把手垫圈	2	2	33	Screw 螺钉	1	1
6	Nut S接管螺母	2	2	20	Nut 把手连接螺母	2	2	34	Body 本体	0	1
7	Screw 螺钉	2	2	21	Handle lever 把手柄	2	2				
8	Locating plate 定位块	2	2	22	Knob 拉杆头	1	0				
9	Body 本体	1	0	23	Screw 螺钉	1	0				
10	Cartridge 阀芯	1	1	24	Lever 连接杆	1	0				
11	Bushing 把手连接套	2	2	25	Washer U型垫	1	0				
12	Screw 螺钉	2	2	26	Spring 弹簧	1	0				
13	Screw 紧固螺钉	2	2	27	Washer 密封圈	1	0				
14	Aerator 起泡器	1	0	28	Lever 密封杆	1	0				


Installation 安装部分

1 S-Connector Installation 安装S型接管



1. Refer to the dimensional drawing and lay the pipes.  
Wash and clean the water supply pipeline.

1. 参考尺寸图，铺设入墙供水管路，  
安装水嘴前，请将铺设好的管路冲洗干净。



2. Install the S-Connector  
2. 将“S形接管”装入供水口

2 Faucet Installation 安装水嘴

