## Test / Usage

### 1 Test

* Move handle down into "OFF" position. Turn on water supply valve to check all connections for leak.
* Operate handle up and down, left and right to flush water lines thoroughly.

### 2 Usage

## Trouble Shooting Guide

| Trouble | Checkpoint | Contents | Action |
|---|---|---|---|
| Poor flow rate | Regulator | Check any impurities. | Remove all impurities. |
| | Angle valve | Check valve position. | Open it to full valve |
| | Flexible hose | Check if hose is twisted. | Untwist the hose. |
| Leakage | Cartridge packing | Check cartridge install. | When packing is damaged, replace the cartridge. |
| | Hose junction | Check the connection. | Check the existence of packing and wind it up sufficiently |

## Care & Maintenance

* If you want to do the maintenance for the faucet, please follow the below process.

① Close the water supply.

**Attention:**
**Please leave the manual to the customer after installation is finished.**



# Milano

FFAS0906–1T2500BT0
Milano Basin Mono

FFAS0926–7T2500BT0
Milano Exposed Shower Mono

FFAS0906–1T2500BT0

FFAS0926–7T2500BT0

American Standard

**Installation & Operation Instructions**

***Thank you for selecting American-Standard - the benchmark of fine quality for over 100 years.***
***To ensure that your installation proceeds smoothly--please read these instructions carefully before you begin.***

* American Standard always keep raising and improving the product design and performance, and reserve the right to modify the dimension and spefication. At this case, we will not inform you separately.
* This installation instruction sheet is for your reference only, the dimension and specification is subject to the actual products.

All instruction procedures must comply in strict accordance with applicable local plumbing and building codes

## Pre–Installation Checks

***Remove all impurity in pipes before beginning to avoid clogging. Connect faucet pipes correctly.**
*** Check installation distances in the Dimension diagram to ensure correct installation.**

### Conditions for use

*** Recommended water pressure condition: 0.1~0.5Mpa.**
*** Environment Temperature:1~55℃**
*** Steam is not allowed to use.**
*** The cold and hot water pipes must not be reserved.**

**When in the process of installation, grab the whole body. Do not grab handle only.**

## Recommended Tools and Materials

Adjustable Wrench

Tape Measure

Windtight Swathe



Pencil

## Dimension

FFAS0906–1T2500BT0

Installation Hole

FFAS0926–7T2500BT0

Rev. FF1–CN521K00047399/A2

## Parts List

FFAS0906–1T2500BT0

| Parts List | | |
|---|---|---|
| No. | Part Name | Q'ty |
| 1 | Index Button | 1 |
| 2 | Screw | 1 |
| 3 | Handle | 1 |
| 4 | Cap | 1 |
| 5 | Nut | 1 |
| 6 | Cartridge | 1 |
| 7 | O–Ring | 1 |
| 8 | Base | 1 |
| 9 | O–Ring | 1 |
| 10 | Body | 1 |
| 11 | Washer | 1 |
| 12 | Aerator | 1 |
| 13 | Washer | 1 |
| 14 | Washer | 1 |
| 15 | Nut | 1 |

FFAS0926–7T2500BT0

| Parts List | | |
|---|---|---|
| No. | Part Name | Q'ty |
| 1 | Index Button | 1 |
| 2 | Screw | 1 |
| 3 | Handle | 1 |
| 4 | Cap | 1 |
| 5 | Nut | 1 |
| 6 | Cartridge | 1 |
| 7 | Body | 1 |
| 8 | Washer | 1 |
| 9 | Escutcheon | 1 |
| 10 | Washer | 1 |
| 11 | Washer | 1 |

## Installation–1 (FFAS0906–1T2500BT0)

### 1 Preparation

1 * Consult the dimension drawing and lay the pipes.
* Wash and clean the water supply pipeline.

### 2 Installation Faucet

## Installation–2 (FFAS0926–7T2500BT0)

1 * Consult the dimension drawing and lay the pipes.
* Wash and clean the water supply pipeline.