


## Test / Usage

### 1 Test

- \* Turn handle to "OFF" position. Open Water supply valve to check all connections for leakage;
- \* Turn handle to "ON" position. Check the water flow .

### 2 Usage




## Trouble Shooting Guide

Trouble	Checkpoint	Contents	Action
Poor flow rate	Aerator	Check any impurities.	Remove all impurities.
	Water supply valve	Check water supply valve open position.	Open it to full water supply valve
	Flexible hose	Check if flexible hose is twisted.	Untwist the flexible hose.
Leakage	Cartridge	Check cartridge packing.	When packing is damaged, replace the cartridge.
	Flexible hose connection	Check if the packing is lost. Check if the connection become loosen	Check the existence of packing and fix it again

## Care & Maintenance

- \* If you want to do the maintenance for the faucet, please follow the below process.
- \* Before maintenance, please shut off the water supply system.



**Attention:**  
Please Leave the manual to the customer  
after installation is finished.


## Milano

FFAS0901-101500BF0  
Milano Basin Mixer

FFAS0902-101500BF0  
Milano Extended Basin Mixer




FFAS0901-101500BF0



FFAS0902-101500BF0

American Standard



Installation &  
Operation Instructions

**To ensure that your installation proceeds smoothly--please read these instructions carefully before you begin.**

- \* Ideal Standard always keep raising and improving the product design and performance, and reserve the right to modify the dimension and specification. At this case, we will not inform you separately.
- \* This installation instruction sheet is for your reference only, the dimension and specification is subject to the actual products.

## Pre-Installation Checks

- \* All instruction procedures must comply in strict accordance with applicable local plumbing and building codes
- \* Remove all impurity in pipes before beginning to avoid clogging. Connect faucet pipes correctly.
- \* Check installation the Dimension Drawing to ensure to install it correctly.

## Conditions for use

- \* Recommended water pressure: 0.1~0.5Mpa.
- \* Environment Temperature:1~55°C
- \* Steam is not allowed.

During installation of the faucet, Please grab the body. Do not grab handle only.

## Recommended Tools and Materials



Adjustable Wrench



Tape Measure




windtight swathe




Pencil

## Dimension

FFAS0901-101500BF0




FFAS0902-101500BF0




Unit: mm

## Parts List




Parts List			
No.	Part Name	Q'ty	
FFAS0901 / FFAS0902			
1	Index Botton	1	1
2	Screw	1	1
3	Handle	1	1
4	Cap	1	1
5	Nut	1	1
6	Cartridge	1	1
7	Body	1	0
8	Washer	1	0
9	Shank	1	0
10	Washer	1	0
11	Washer	1	0
12	Nut	1	0
13	Hose (Blue)	1	0
14	Hose (Red)	1	0
15	Aerator	1	1
16	O-Ring	0	1
17	Valve Seat	0	1
18	Body	0	1
19	Shank	0	1
20	Washer	0	1
21	Hold Plate	0	1
22	Washer	0	1
23	Nut	0	1
24	Hose (Red)	0	1
25	Hose (Blue)	0	1
26	Lift Knob	1	0
27	Lift Rod	1	0
28	Pop-up Drain	1	0
29	Press-action Pop-up Drain	0	1



## Installation


### 1 Preparation



- \* Consult the dimension drawing and lay the pipes.
- \* Wash and clean the water supply pipeline.




### 2 Installing the Faucet



### 3 Installing the Drain

#### \* Installing the Pop-up Drain



#### \* Installing the Press-action Pop-up Drain

